



Skyliner™ Technical Bulletin 001: **Skyliner™ Uses Less Banding**

The Skyliner™ System uses less banding in the parallel building direction compared to other liner systems. The Skyliner™ System Roof Installation Instructions, Step 3 states: "One 1-inch parallel band is needed for each purlin space, running from end wall to end wall, and centered in the purlin space. One parallel band is required on each side of ridge purlins."

The Skyliner™ System is shipped with sufficient banding for parallel and perpendicular banding according to the Skyliner™ Installation Manual. Installing more than one parallel band between purlins will cause project banding shortages.

Installing banding, safety clips (adjacent to frames), adhesive, and Skyliner™ fabric according to Skyliner™ instruction manual reduces installation time and meets OSHA Standard 29 CFR 1926.502(c)(4)(i) for leading-edge fall protection.

**Questions? Contact your Bay District
Manager, call 844.999.7153 or visit
www.SkylinerSystems.com.**

(Actual fabric)

