



Skyliner™ Technical Bulletin 003: **Skyliner™ Adhesive Application**

Skyliner™ adhesive is a contact adhesive. The adhesive must be **applied to two surfaces** in order to bond together properly and meet OSHA leading-edge fall protection criteria.

Skyliner™ System Roof Installation Instructions – Step 5 states: “Apply adhesive to top of frame and to fabric tab. (Adhesive must be applied as contact adhesive to both surfaces.) Allow adhesive to tack. Then fold tab created by relief cuts over the frame, adhering the fabric onto the frame between each purlin.”

Alternative method: Apply as a single coat to the frame, apply the fabric liner, remove fabric liner (now both sides are coated), then reattach.

The Skyliner™ System adhesive will only work as a contact adhesive when two surfaces are coated.

Installing banding, safety clips (adjacent to frames), adhesive, and skyliner fabric (on roll) according to Skyliner™ Instruction Manual meets OSHA Standard 29 CFR 1926.502(c)(4)(i) for leading-edge fall protection.

**Questions? Contact your Bay District
Manager, call 844.999.7153 or visit
www.SkylinerSystems.com.**

(Actual fabric)

